

DeltaSol[®] MiniPool

RESOL[®]

Controller for heating a swimming pool


Manual for the specialised craftsman

Installation

Operation

Functions and options

Troubleshooting



48004881

Thank you for buying this RESOL product.
Please read this manual carefully to get the best performance from this unit.
Please keep this manual safe.

en

Manual

www.resol.com

Safety advice

Please pay attention to the following safety advice in order to avoid danger and damage to people and property.

Instructions

Attention must be paid to the valid local standards, regulations and directives!

Information about the product

Proper usage

The *DeltaSol*® MiniPool is to be used for heating a swimming pool by means of solar collectors and optimised operation of the filter system in compliance with the technical data specified in this manual.

Improper use excludes all liability claims.

CE Declaration of conformity

The product complies with the relevant directives and is therefore labelled with the CE mark. The Declaration of Conformity is available upon request, please contact the manufacturer.



Note:

Strong electromagnetic fields can impair the function of the controller.

- Make sure the controller as well as the system are not exposed to strong electromagnetic fields.

Subject to technical change. Errors excepted.

Target group

These instructions are exclusively addressed to authorised skilled personnel.

Only qualified electricians should carry out electrical works.

Initial installation must be effected by the system owner or qualified personnel named by the system owner.

Description of symbols

WARNING!

Warnings are indicated with a warning triangle!



→ They contain information on how to avoid the danger described.

Signal words describe the danger that may occur, when it is not avoided.

- **WARNING** means that injury, possibly life-threatening injury, can occur.
- **ATTENTION** means that damage to the appliance can occur.



Note:

Notes are indicated with an information symbol.

- Arrows indicate instruction steps that should be carried out.

Disposal

- Dispose of the packaging in an environmentally sound manner.
- Dispose of old appliances in an environmentally sound manner. Upon request we will take back your old appliances bought from us and guarantee an environmentally sound disposal of the devices.

The DeltaSol® Minipool is a controller for heating a swimming pool by means of solar collectors and optimised operation of the filter system. Furthermore, the controller has many additional pool functions such as: maximum limitation of flow temperature, pool cooling function and a flushing function.


The DeltaSol® Minipool can easily be connected to other modules via the VBus®.

Contents

1 Overview	4	6 Menu structure	10
2 Installation	5	6.1 Display values	10
2.1 Mounting	5	6.2 Balance values	10
2.2 Electrical connection	6	6.3 Functions/Adjustment values	10
2.3 Data communication/Bus	6	7 Functions and options	11
3 Basic system	7	8 Error indication	13
4 Operation and function	8	9 Troubleshooting	14
4.1 Push buttons	8	10 Accessories	14
4.2 Operational concept	8		
5 Status display	9		

1 Overview

- 4 sensor inputs and 2 relay outputs
- Filter runtime monitoring
- Maximum flow temperature limitation
- Cooling function
- Collector emergency shutdown
- Heat quantity measurement
- Operating hours counter



Technical data

Inputs: 4 Pt1000 temperature sensors

Outputs: 2 semiconductor relays

Switching capacity: 0,5 (0,5) A 240 V~ (semiconductor relay)

Total switching capacity: 0.8 A 240 V~

Power supply: 220 ... 240 V~ (50 ... 60 Hz)

Supply connection: type Y attachment

Standby: ca. 2 W

Mode of operation: type 1.C.Y action

Rated impulse voltage: 2.5 kV

Data interface: RESOL VBus®

VBus® current supply: 30 mA

Functions: function control, filter runtime monitoring, maximum flow temperature limitation, cooling function, collector emergency shutdown, heat quantity measurement, operating hours counter

Housing: plastic, PC-ABS and PMMA

Mounting: wall mounting, mounting into patch panels is possible

Indication/Display: graphic display, 160 x 64 pixels

Operation: 3 push buttons at the front

Ingress protection: IP 20/EN 60529

Protection class: I

Ambient temperature: 0 ... 40 °C

Pollution degree: 2

Dimensions: 173 x 110 x 47 mm

2 Installation

2.1 Mounting

WARNING! Electric shock!



Upon opening the housing, live parts are exposed!

→ **Always disconnect the controller from power supply before opening the housing!**

ATTENTION! ESD damage!




Electrostatic discharge can lead to damage to electronic components!

→ **Take care to discharge properly before touching the inside of the device! To do so, touch a grounded surface such as a radiator or tap!**

The unit must only be located in dry interior rooms. It is not suitable for installation in hazardous locations and should be protected against electromagnetic fields. The controller must additionally be supplied from a double pole switch with contact gap of at least 3 mm. Please pay attention to separate routing of sensor cables and mains cables.

- Unscrew the crosshead screw from the cover.
- Pull the cover downwards to remove it from the housing.
- Mark the upper fastening point on the wall, drill and fasten the enclosed wall plug and screw leaving the head protruding.
- Hang the housing from the upper fastening point and mark the lower fastening point through the hole in the terminal box (centres 130 mm). Drill and insert the lower wall plug.
- Fasten the housing to the wall with lower fastening screw and tighten.
- Carry out the electrical connections according to the specifications.
- Refasten the cover.



2.2 Electrical connection

WARNING! Electric shock!



Upon opening the housing, live parts are exposed!

→ **Always disconnect the controller from power supply before opening the housing!**

ATTENTION! ESD damage!



Electrostatic discharge can lead to damage to electronic components!

→ **Take care to discharge properly before touching the inside of the device! To do so, touch a grounded surface such as a radiator or tap!**



Note:

It must be possible to disconnect the device from the mains at any time.

- Install the mains plug such that it is accessible at any time.
- If this is not possible, install a switch that can be accessed.



Note:

Connecting the device to the power supply must always be the last step of the installation!

→ Do not use the device if it is visibly damaged!

The power supply of the device must be 220 ... 240 V~ (50 ... 60 Hz).

The controller is equipped with two relays to which loads can be connected:

- **Relays R1/R2** are electromechanical relays:

R1/R2 = conductor R1 ... R2

N = neutral conductor N (common terminal block)

PE = protective conductor PE (common terminal block)

Depending on the product version, mains cable and sensor cables are already connected to the device. If that is not the case, please proceed as follows:

Connect the **temperature sensors** (S1 to S4) to the corresponding terminals with either polarity.

Connect the **mains cable** to the following terminals:

19 = neutral conductor N

20 = conductor L

12 = protective conductor (⊕)


2.3 Data communication/Bus

The controller is equipped with the RESOL VBus® for data transfer with and energy supply to external modules. The connection is carried out at the two terminals marked "VBus" (either polarity). One or more RESOL VBus® modules can be connected via this data bus:




VBus® terminals

- RESOL DL2 Datalogger
- RESOL GA3 Large Display
- RESOL SD3 Smart Display
- RESOL STA-W kWh output module
- RESOL VBus®/USB Interface adapter



3 Basic system



Sensor allocation

S1	S2	S3	S4
Tabсорber	Tpool	Tflow	T - freely selectable

Relay allocation


R1	R2
Filter pump P1	3-way valve V1 Solar: on/off

Sensor abbreviations

Sensor	Description
Tabсорber	Absorber temperature
Tpool	Pool temperature
Tflow	Flow temperature
S4	freely selectable; with WMZ Treturn
Treturn	Return temperature

4 Operation and function

4.1 Push buttons




The controller is operated via the three push buttons below the display. The forward-button (1) is used for scrolling forward through the menu or to increase the adjustment values. The backward-button (2) is similarly used for scrolling backwards and reducing values. Button 3 is used for selection of the menu lines and for confirmation.

4.2 Operational concept

Adjustment mode

In the adjustment mode, different functions can be selected and values can be adjusted.

- To access the adjustment mode, scroll down past the last adjustment channel and press button 1 for approx. three seconds.
- Select the desired value or function by pressing buttons 1 and 2, then confirm by pressing button 3



Adjusting values:

- Select the value by pressing buttons 1 or 2, then briefly press button 3; the adjustment range is displayed in the form of a bar.
- Adjust the desired value by pressing buttons 1 and 2; this value is shown on the bar by means of a slider.
- Briefly press button 3 to confirm the adjustment.
- Press button 3 again to store the adjustment. The controller will then go back to the adjustment menu.

If button 3 is not pressed after the adjustment, the display will go back after a few seconds. The adjustment will not be stored.

Minimum filter runtime:	
<input type="radio"/> No	
<input checked="" type="radio"/> Yes	

Adjustments:	
<input checked="" type="checkbox"/> Minimum filter runtime	
Filtration period	1 h
<input type="checkbox"/> Filter ending time	12:00

Selecting a function or option:

- Select the desired function or option by pressing buttons 1 and 2, then briefly press button 3.
- Select *YES* to activate the selected function, or select *NO* to deactivate the function.
- Briefly press button 3 to confirm the selection.
- Press button 3 again to store the adjustment.
- An activated function is indicated by means of a marked checkbox. Additionally, the corresponding adjustment values are displayed.
- In order to leave the adjustment mode and get back to the display mode, keep button 2 pressed until the first menu item of the main menu is reached.
- Then briefly press button 2 to get back to the display mode.

If no button is pressed for two minutes, the controller will automatically go back to the status display.

5 Status display

In the status display, the operating status of the system is indicated:

SOLAR: ON: Solar loading is active

SOLAR: OFF: Solar loading is inactive

COOLING: Cooling is active, pool temperature is displayed

FILTRATION: Filter pump is active; the remaining time is displayed

Additionally, possible causes for the *SOLAR: ON* and *SOLAR: OFF* status of the system are indicated:

POOL MAX.: Maximum pool temperature is reached

FLOW MAX.: Maximum flow temperature is reached

ABS. MAX.: Maximum absorber temperature is reached

ABS. MIN.: Minimum absorber temperature is reached

SENSOR FAILURE

MIN. ON: Minimum runtime is active

MIN. OFF: Minimum break time is active

6 Menu structure

6.1 Display values

The following values are displayed:

Display	Description
<i>TABSORBER</i>	Absorber temperature in °C
<i>TPOOL</i>	Pool temperature in °C
<i>TFLOW</i>	Flow temperature in °C
<i>SENSOR4</i>	Temperature at an additional sensor location
<i>TIME</i>	Time
<i>FILTER RUNTIME</i>	Present-day runtime of the filter pump
<i>RELAY1</i>	Relay1 on/off
<i>RELAY2</i>	Relay2 on/off

6.2 Balance values

The following values can be charted:

Display	Description
<i>MAX. TABS.</i>	Maximum absorber temperature
<i>MIN. TABS.</i>	Minimum absorber temperature
<i>MAX. TPOOL</i>	Maximum pool temperature
<i>MIN. TPOOL</i>	Minimum pool temperature
<i>MAX. TFLOW</i>	Maximum flow temperature
<i>MIN. TFLOW</i>	Minimum flow temperature
<i>MAX. SENSOR4</i>	Maximum outdoor temperature
<i>MIN. SENSOR4</i>	Minimum outdoor temperature
<i>OPER. DAYS</i>	Number of operating days of the controller
<i>OPER. HOURS R1</i>	Operating hours of the filter pump (P1 at R1)
<i>OPER. HOURS R2</i>	Solar loading operating hours (V1 at R2)

6.3 Functions/Adjustment values

Display	Description
<i>ΔTON</i>	Switch-on difference
<i>ΔTOFF</i>	Switch-off difference
<i>POOLMAX</i>	Maximum pool temperature
<i>T-ΔTON</i>	Delay
<i>MIN ON</i>	Minimum runtime
<i>MIN OFF</i>	Minimum break time
<i>TIME</i>	Time
<i>MINIMUM FILTER RUNTIME</i>	Minimum filter runtime
<i>CIRCULATION</i>	Circulation function
<i>FLOWMAX.</i>	Maximum flow limitation
<i>ABSORBERMAX.</i>	Absorber maximum limitation
<i>ABSORBERMIN.</i>	Absorber minimum limitation
<i>POOLCOOLING</i>	Pool cooling

For more detailed information about the functions and the corresponding adjustment values see ch. 7, page 11.

7 Functions and options

Switch-on difference

ADJUSTMENTS/ Δ T_{ON}

Adjustment range: 0.2 ... 25.0 K

Factory setting: 2.5 K

Adjustment of the switch-on difference (*T_{ABSORBER} - T_{POOL}*) for the solar circuit in Kelvin.

Switch-off difference

ADJUSTMENTS/ Δ T_{OFF}

Adjustment range: 0.0 ... 24.8 K

Factory setting: 0.3 K

Adjustment of the switch-off difference (*T_{FLOW} - T_{POOL}*) for the solar circuit in Kelvin. The switch-off difference has to be at least 0.2 K lower than the switch-on difference Δ T_{ON}.

Maximum pool temperature

ADJUSTMENTS/POOLMAX

Adjustment range: 10 ... 40 °C

Factory setting: 28 °C

Adjustment of the maximum pool temperature in °C.

When the adjusted maximum pool temperature is reached, the solar system switches off. The circulation function is not inhibited.

Switch-on delay

ADJUSTMENTS/T- Δ T_{ON}

Adjustment range: 00:01 ... 10:00

Factory setting: 01:00

Adjustment of the switch-on delay *T- Δ T_{ON}*. The switch-on conditions must be fulfilled for this period of time for the solar loading to start.

- ➔ First adjust the minutes and confirm the adjustment.
- ➔ Then adjust the seconds and confirm the adjustment.

Minimum runtime

ADJUSTMENTS/MIN ON

Adjustment range: 0 ... 10 min

Factory setting: 2 min

Adjustment of the minimum runtime in minutes.

The minimum time for which the solar system remains switched on after the switch-on conditions have been fulfilled. The minimum runtime is not aborted by the maximum pool temperature limitation.

Minimum break time

ADJUSTMENTS/MIN OFF

Adjustment range: 0 ... 10 min

Factory setting: 2 min

Adjustment of the minimum break time in minutes.

The period of time for which the solar system remains switched off after the switch-off condition has been fulfilled.

Time

ADJUSTMENTS/TIME

Adjustment of the current time

Minimum filter runtime

ADJUSTMENTS/MINIMUM FILTER RUNTIME

Selection: "Yes", "No"

Factory setting: "No"

ADJUSTMENTS/FILTRATION PERIOD

Adjustment range: 0 ... 16 h

Factory setting: 5 h

ADJUSTMENTS/ENDING TIME

Adjustment range: 00:00 ... 23:30

Factory setting: 20:00

Adjustment of the minimum filter pump runtime in hours.

The filter pump is switched on for this adjusted *FILTRATION PERIOD* every day.

The filter runtime ends when the adjusted *ENDING TIME* is reached.

The minimum filter runtime will also be complied with in the case of a sensor failure.

Example: With a filter runtime of 4 hours, the filter pump has to be continuously active from 16:00 o'clock on in order to reach the adjusted runtime before the adjusted ending time at 20:00 o'clock is reached.

Circulation function

ADJUSTMENTS/CIRCULATION

Selection: "Yes", "No"

Factory setting: "No"

If the solar system has not been active for the period of one hour, it will be switched on for 1 ... 10 minutes (Flushing the pipes with pool water in order to measure the pool temperature during a system standstill).

ADJUSTMENTS/STARTING TIME

Adjustment range: 00:00 ... 23:45

Factory setting: 07:00

ADJUSTMENTS/STOPPING TIME

Adjustment range: 00:15 ... 24:00

Factory setting: 20:00

Start/end of the circulation period (time).

ADJUSTMENTS/PERIOD

Adjustment range: 1 ... 10 min

Factory setting: 1 min

Adjustment of the circulation duration in minutes.

Flow maximum limitation

ADJUSTMENTS/FLOWMAX

Selection: "Yes", "No"

Factory setting: "Yes"

ADJUSTMENTS/TFLOWMAX

Adjustment range: 30 ... 100 °C

Factory setting: 40 °C

Adjustment of the flow maximum limitation.

If this function is active, solar loading will be switched off when the maximum flow temperature is exceeded (scald protection).

Absorber maximum limitation

ADJUSTMENTS/ABSORBERMAX

Selection: "Yes", "No"

Factory setting: "No"

The absorber maximum limitation inhibits solar loading from the absorber if the adjusted temperature threshold (*TABS.MAX*) is exceeded.

ADJUSTMENTS/TABS.MAX

Adjustment range: 60 ... 160 °C

Factory setting: 130 °C

ADJUSTMENTS /ΔTABS.MAX

Adjustment range: 2 ... 50 K

Factory setting: 10 K

Adjustable switch-on and switch-off hysteresis (*ΔTABS.MAX*) which prevents the controller from switching on and off again because of very small temperature differences.

Absorber minimum limitation

ADJUSTMENTS/ABSORBERMIN

Selection: "Yes", "No"

Factory setting: "No"

This function ensures that a solar loading is only effected if a given absorber temperature is exceeded.

ADJUSTMENTS/TABS.MIN

Adjustment range: 10 ... 90 °C

Factory setting: 10 °C

ADJUSTMENTS/ΔTABS.MIN

Adjustment range: 0.3 ... 10 K

Factory setting: 2.0 K

Adjustable switch-on and switch-off hysteresis (*ΔTABS.MIN*) which prevents the controller from switching on and off again because of very small temperature differences.

Pool cooling function

ADJUSTMENTS/POOLCOOLING

Selection: "Yes", "No"

Factory setting: "No"

EXPERTE/ADJUSTMENTS/ Δ TCOOL

Adjustment range: 0.3 ... 10.0 K

Factory setting: 2.0 K

If the maximum pool temperature is exceeded by a certain value (Δ TCOOL), this function cools the pool by discharging heat through the absorber. This is only possible if the absorber is cooler than the pool by the adjusted temperature difference Δ TCOOLON.

Cooling is switched off when the value Δ TCOOLOFF is reached or when POOLMAX is underrun.

EXPERTE/ADJUSTMENTS/ Δ TCOOLON

Adjustment range: 0.3 ... 10.0 K

Factory setting: 3.0 K

EXPERTE/ADJUSTMENTS/ Δ TCOOLOFF

Adjustment range: 0.2 ... 10.0 K

Factory setting: 1.5 K

The adjustable minimum difference between switch-on and switch-off temperature (hysteresis) prevents the controller from switching on and off again due to very small temperature differences..

Heat quantity balancing

ADJUSTMENTS/HEAT QUANTITY

Selection: "Yes", "No"

Factory setting: "No"

ADJUSTMENTS/FLOW RATE

Adjustment range: 0.1 ... 500 l/min

Factory setting: 5 l/min

Heat quantity balancing is possible if a flowmeter is used.

The flow rate should be read from the window of the flow setter at 100 % pump speed and must be adjusted as FLOW RATE.



Note

For heat quantity balancing, S4 has to be used for measuring the return temperature (see chap. 3).

Manual operation

MANUAL OPERATION/RELAY1 (2)

Selection: "Off", "On", "Auto"

Factory setting: "Auto"

Each relay can be set into the OFF/ON/AUTO mode. During normal operation, the relay is set to AUTO.

Sensors

Sensor Offset

Sensor1 (2, 3, 4)

Adjustment of the sensor offset.

A sensor offset can be carried out (-5 K ... +5 K, adjustment step size 0.1 K).

Language

LANGUAGE

Selection: "Deutsch", "English", "français", "castellano", "italiano"

Factory setting: "Deutsch"


Adjustment of the menu language: DEUTSCH, ENGLISH, FRANCAIS, CASTELLANO, ITALIANO.

8 Error indication

A possible failure of the pool-, flow- or absorber sensor will be indicated on the display. The solar system will be switched off or, if already off, remain inactive. In the case of a failure of the outdoor temperature sensor, the system will not be switched off or kept inactive.

9 Troubleshooting

If a malfunction occurs, a message is displayed in the display of the controller:



Operating control lamp off.

Check the power supply. Is it disconnected?

no

The fuse of the controller could be blown. It can be replaced after the front cover has been removed (spare fuse is enclosed in the accessory bag).

yes

Check the supply line and reconnect it.

10 Accessories

10.1 Sensors and measuring instruments



Sensors

Our product range includes high-precision platinum temperature sensors, flatscrew sensors, outdoor temperature sensors, indoor temperature sensors, cylindrical clip-on sensors, also as complete sensors with immersion sleeve.



Overvoltage protection device

In order to avoid overvoltage damage at collector sensors (e.g. caused by local lightning storms), we recommend the overvoltage protection RESOL SP10.

10.2 VBus® accessories



AM1 Alarm module

The AM1 alarm module is designed to signal system failures. It is to be connected to the VBus® of the controller and issues an optical signal via a red LED if a failure has occurred. The AM1 also has a potential-free relay output, which can e.g. be connected to a building management system (BMS). Thus, a collective error message can be issued in the case of a system failure.



DL2 Datalogger

This additional module enables the acquisition and storage of large amounts of data (such as measuring and balance values of the solar system) over a long period of time. The DL2 can be configured and read-out with a standard internet browser via its integrated web interface. For transmission of the data stored in the internal memory of the DL2 to a PC, an SD card can be used.

The DL2 is appropriate for all controllers with RESOL VBus®. It can be connected directly to a PC or router for remote access and thus enables comfortable system monitoring for yield monitoring or for diagnostics of faults.

10.3 Interface adapters



VBus®/USB interface adapter

The new VBus®/USB interface adapter is the interface between the controller and a personal computer. With its standard mini-USB port it enables a fast transmission of system data via the VBus® for processing, visualizing and archiving. A full version of the RESOL ServiceCenter software is included.



Moisture-proof housing

Moisture-proof housing for controller installation outdoors or in highly humid locations

Distributed by:

RESOL – Elektronische Regelungen GmbH

Heiskampstraße 10
45527 Hattingen / Germany

Tel.: +49 (0) 23 24 / 96 48 - 0

Fax: +49 (0) 23 24 / 96 48 - 755

www.resol.com

info@resol.com

Important note

The texts and drawings in this manual are correct to the best of our knowledge. As faults can never be excluded, please note:

Your own calculations and plans, under consideration of the current standards and directions should only be basis for your projects. We do not offer a guarantee for the completeness of the drawings and texts of this manual - they only represent some examples. They can only be used at your own risk. No liability is assumed for incorrect, incomplete or false information and / or the resulting damages.

Note

The design and the specifications can be changed without notice.

The illustrations may differ from the original product.

Imprint

This mounting- and operation manual including all parts is copyrighted. Another use outside the copyright requires the approval of **RESOL – Elektronische Regelungen GmbH**. This especially applies for copies, translations, micro films and the storage into electronic systems.

© **RESOL – Elektronische Regelungen GmbH**